

User Guide: Button Maker



What is it?

The Button Maker turns your print or hand-drawn designs into wearable buttons! Buttons may be pinned onto your t-shirt, backpack, jacket, and more. Button size is 2¼ inches.

[Button Maker User Manual](#)

Cost:

- 50¢/button

[Click here to see what size to make your art and the size of the button.](#)

What can I do?

Make buttons for gifts, parties, special occasions, or simply as a fashion statement.

What does the Makerspace provide?

- Button press – 2 ¼ inch buttons
- Circle cutter

Thibodaux Branch Makerspace

- The metal parts of the button
 - 2 ¼ inches: 50¢/button

What do I need?

- A design either printed or drawn
 - \$0.10/page BW Printing
 - \$0.50/page Color Printing

What materials can I use?

- Paper must be 20 lb. The button press will not work with card stock, photo paper, or construction paper.
- Microsoft Word is great for beginners who need to resize an image.
- Always have extra print outs or paper to practice cutting the circles. If the circle is not cut well, the button press will not work.

Learn

- Watch [Badge a Minit How To Make a Button Video](#)

Reserve the Button Makers

Reserve

- Call (985) 447-4119 or email thibodaux@lafourche.org about your reservation
 - Reservations are held for 15 minutes after start time.
 - Cardholder must be present during reservation.